



STANDARD  
TELE




==== OUT  
==== GROUND

REVERSE (RWRP)  
TELE




==== OUT  
==== GROUND

STANDARD TAP  
TELE BRIDGE




==== OUT2 (FULL)  
==== OUT1  
==== GROUND

REVERSE TAP (RWRP)  
TELE NECK



==== OUT2 (FULL)  
==== OUT1  
==== GROUND

REVERSE (RWRP)  
TELE MINI-HUMBUCKER




==== OUT  
==== SPLIT  
==== GROUND

REVERSE TAP (RWRP)  
TELE NECK




==== OUT2 (FULL)  
==== OUT1  
==== GROUND

STANDARD  
TELE



==== OUT  
==== GROUND

REVERSE (RWRP)  
TELE



==== OUT  
==== SPLIT  
==== GROUND