



HUMBUCKER(B+RUNNER TAP(M))+RUNNER STACK(N)
Volume, Tone, Tone, 5 way switch, push-pull (split)

C1=.022uf