



HUMBUCKER(B)+RUNNER TAP(M)+RUNNER TAP(N)
Volume, Tone, 5 way switch, Push Pull (split)

C1=.022uf